
Save time and money

Xtratus PC Tool $^{\text{m}}$ allows big savings at service and trouble shooting.




You only need a standard USB A / USB B cable to connect your laptop to an Xtratus® Fog Cannon™.



The Xtratus PC Tool™ front panel shows all inputs and outputs, status and errors in real time.

Xtratus PC-Tool™

Xtratus PC Tool™ is a diagnostic PC application, which can retrieve both real-time information and the logged data stored in the Fog Cannon™. Using Xtratus PC Tool™ will help you significantly during installation and maintenance, saving time and improving customer satisfaction.



Features:

- Intuitive graphical user interface
- Embedded descriptions of all I/O
- Read status
- Xtratus Flex® Vx.30 added features:
 - Read log
 - Read errors
 - Read DIP
 - Block
- · Free of charge
- Connect your PC with a standard, cheap USB A / USB B cable
- With your dealer login, you can download the application on https://downloadcenter. protectglobal.com

Specifications:

All Xtratus® firmware versions:

Read out all I/O: Battery voltage, PIR current, motor status, heater status and temperature, mains status and interface signals for alarm panel.

Embedded descriptions of all I/O to ease installation and troubleshooting. Simply place the cursor over the I/O you want info on, and a description of that I/O will pop up. In most cases, this will eliminate the need for the full manual on-site.

Added features for Xtratus Flex® Vx.30:

Read out the event log. This can be useful in connection with a burglary, or troubleshooting.

The event log can be saved as a file and sent to PROTECT A/S technical support to assist with troubleshooting.

Read out all current errors.

Read out DIP settings in real-time, and secure that the Fog Cannon™ is set up correctly.

Block the Fog Cannon $^{\!\scriptscriptstyle{\mbox{\scriptsize{M}}}}$ to avoid accidental fog release when working on the machine.

We reserve the rights to modify due to misprint or changes in the technical data.

